

- Instructions for inbuilt controller 內建控制板說明:
  - 1. Make sure 1 \ 2 \ 9 are well connected.

先確認 (1)、(2)、(9) 端子位置皆連接正確

- 2. Connect the fan ARGB connectors with ③~⑧ 連接ARGB風扇訊號線 ③~⑧ 位置
- 3. Connect SATA Connector with (9)

連接 ⑨ SATA電源

4. Press the Power button on the case.

開啟機箱Power按鍵

- 5. Press the LED mode button on the I/O port; enjoy more than 13 light effects. 操作I/O 上LED控制按鍵·超過13種以上燈效模式
- If you would like it to work in sync with the motherboard, please connect 1 the 3-pin connector with the motherboard.

如需與主板ARGB同步操作,請將 ① 3pin接線連接至主機板

 Long press the LED button for 3-6 seconds and wait for white light blinking twice, and it will change to motherboard sync mode.

長按I/O上LED控制按鍵3~6秒·待連續兩次白光閃爍時·將會切換至與主板同步模式。

2. If you would like to use the LED button on the I/O port, slightly press it, and it will return to the inbuilt controller mode.

如欲切回機殼內建燈光控制板,請至I/O上輕按LED控制按鍵,將回到機殼內建燈光控制板燈效模式。

3. If you press the LED button for more than 6 seconds, the light effects will be turned off after the white light blinks 4 times. Press the LED button again, and it will return to the inbuilt controller mode.

如長按I/O上LED控制按鍵大於6秒·LED將會在4次白光閃爍後自動關閉燈光· 再按一次I/O上LED控制按鍵則恢復內建燈光模式。

