


















# SKELETON 360


MANUAL

## ACCESSORIES


<b>A</b>  Intel Backplate x1	<b>B</b>  Intel Backplate x2	<b>C</b>  AMD Backplate x2	<b>D</b>  Backplate x2
<b>E</b>  x4	<b>F</b>  x4	<b>G</b>  x4	<b>H</b>  x12
<b>I</b>  x12	<b>J</b>  x4	<b>K</b>  x1	<b>L</b>  x1
<b>M</b>  x1	<b>N</b>  x3	<b>O</b>  x1	

## INTEL PLATFORM INSTALLATION


### Intel 115X / 1200 / 1700 / 1851




### Intel 115X / 1200




### Intel 1700 / 1851




### Intel 20XX




AMD PLATFORM INSTALLATION



INSTALL THE PUMPHEAD & FAN



RADIATOR INSTALLATION



**Antec**  
BELIEVE IT

[www.Antec.com](http://www.Antec.com)

All rights reserved. Specifications are subject to change without prior notice. Actual products and accessories may differ from illustrations. Omissions and printing errors excepted. Content of delivery might differ in different countries or areas. Some trademarks may be claimed as the property of others.

©1986 – 2025 Antec Inc. All rights reserved.